

INSTALL DTF R2R FIRMWARE


This is a guide how to install the DTF R2R firmware after the conversion of a GTXpro (Bulk) to a GTXpro (Bulk) Roll.

INSTALLATION BY USB STICK

The GTXpro must be switched on and completely booted.
Connect the USB-stick to the printer.


Only use the enclosed USB-stick! Do not reproduce this stick.

Go to the advanced menu.



A: Press Menu/OK on the operation panel to enter in the Menu.



B: Press once




C: Press and hold

D: Press and hold


E: Press and hold



Choose FIRMWARE UPDATE



F: Press once
G: Press once



H: Press once

Wait until the installation is done. **Do not touch the stick during installation.**
 Then turn the printer off and on again. Now remove the USB-stick.