GTX600 SB



We share our experience to give you the best Support

7,5k Maintenance

This is a guide on how to perform all 7,5k maintenances – 7,5k, 15k, 22,55k etc.

Use only original Spare Parts to keep your **GTX600 SB** always in best condition to get the best out of it.

Note that **GTX600 SB** is always updated with the latest firmware and driver.

To do	Spare Part Name (Pieces)	Spare Part Number	Quantity
Clean surrounding/replace	MIST FAN FILTER SET (2)	SC5066001	1

Vacuum cleaner Waste cloth





Mist Fan Filter Set

Necessary tools: Estimated time:
GTX600 key Around 15 minutes
Gloves

Replacing the mist fan filter

Start from the menu:





Maintenance Part Clean/Replace
Clean nozzle guard and cap
Replace maintenance unit parts
Replace mist fan filter

Replace mist fan filter

Platen will move
for operation

Press OK to move

Replace mist fan filter
Check if all doors are closed

Check doors and press [OK]

Replace mist fan filter

Keep Hands away
Platen is moving


Replace mist fan filter

Perform replacement


Clean all areas around the Mist Fan Filter with vacuum cleaner and waste cloth to remove all dust clumps. Replace the Mist Fan Filter. Do not use Cleaning Solution.




A: Position of the Mist Fan Filter



Clean the doors of the Mist Fan Filter and the surrounding area




Open cover on right and left side of the **GTX600 SB** for cleaning cavities above the Mist Fan Filter




B: Push and release **C:** Open the cover











Insert the new Filter and close the compartment

Replace mist fan filter

Perform replacement

Press [OK]

You finished the 7,5k maintenance.